


INTERCONNECT WIRING NOTES

1. CREATE PAPER LABEL WITH JAC P/N "CAB-WJAC-0008, Rev A, BT. #xxxx, Made in Canada".
2. PLACE PAPER LABEL INSIDE M2 LOCATED CLOSE TO P1 END.

PREPARED	TAT			
CHECKED				
APPROVED		NCAGE CODE L00N3	PART NO. CAB-WJAC-0008	SHEET 1/1
CONFIDENTIAL & PROPRIETARY TO JUPITER AVIONICS CORP.		DOC NO. CAB-WJAC-0008 Interconnect Rev A.dwg		