




JUPITER AVIONICS
CORPORATION

JA31-001 Intercom Bus Selector



Operating Manual

Rev. A



**Copyright 2015 Jupiter Avionics Corp.
All rights reserved**

Jupiter Avionics Corporation (JAC) permits a single copy of this manual to be printed or downloaded for personal use. Any such electronic or printed copy of this manual must contain the complete text of this copyright notice. Any unauthorized commercial distribution of this manual is strictly prohibited. Except as described above, no part of this manual may be reproduced, copied, transmitted, disseminated, downloaded, or stored in any storage medium for any purpose without the express prior written consent of JAC.

IMPORTANT:
**Information in this manual is subject to
change without notice.**

To check the current revision status of
this manual, visit the JAC website:
www.jupiteravionics.com

Record of Revisions			
Rev	Date	Description	ECR
A	May 2015	Initial release, serial number 1001 +	2457



Prepared: MPB	Checked: 	Approved: 
----------------------	---	--



Table of Contents

1	Introduction	1
2	Front Panel Controls	1
(1)	User/Crew Member Designation	1
(2)	Intercom Bus Selector Legends	1
(3)	Intercom Bus Selector Switches	1
3	Operation	2
3.1	Panel Lighting	2
3.2	BUS Selection (Talk Groups)	2




1 Introduction

This manual contains the operating instructions for the JA31-001.



Note: The 6 legends are removable and may be replaced with custom ordered parts. The controls are referred to by the default legend names as shown below.

2 Front Panel Controls



(1) User/Crew Member Designation

The four User Designation legends are interchangeable to allow customization.

(Default – USER1; USER2; USER3; USER4.)

(2) Intercom Bus Selector Legends

The two Intercom Bus Selector Legends are interchangeable to allow for customization.

(Default – BUS1, BUS2.)

(3) Intercom Bus Selector Switches

The Intercom Bus Selector Switches are four white two-position toggle switches that allow each user to select the Intercom Bus for connection. When the switch associated with the user is in the UP position, the user will be connected to BUS 1, and in the DOWN position the user will be connected to BUS 2.



3 Operation



Note: The JA31-001 does not require power from the aircraft for operation.

3.1 Panel Lighting

The legends will be illuminated and dim through the aircraft lighting bus.


3.2 BUS Selection (Talk Groups)

When the USER switch is in the BUS 1 position, the USER's ICS Tie Line will be connected to Bus 1.

When the USER switch is in the BUS 2 position, the USER's ICS Tie Line will be connected to Bus 2.

3.2.1 JA31-001 for Talk Groups/Isolation

ALL USERS



If it is a requirement for **ALL USERS** to be able to talk together on the intercom, all users' switches must either select BUS 1 or BUS 2 (i.e. all switches in the same direction.)


ISOLATION



If one user is to be **ISOLATED** from the other users, that user must be connected to a different bus to all the other users. (i.e. User's switch must be in the opposite direction to all the others.) In this example, User 4 is isolated from Users 1, 2 and 3.



SPLIT USE (Talk Groups)



If it is necessary to **SPLIT** the users into Talk Groups, (for instance Flight Crew and Cabin Crew) the users' switches should be connected to different busses (in this example, User 1 and User 2 are connected on BUS 2; User 3 and User 4 are connected on BUS 1).



JUPITER AVIONICS
CORPORATION

Jupiter Avionics Corporation
1959 Kirschner Road
Kelowna BC
Canada V1Y 4N7
Tel: +1 778 478 2232
Toll-Free: 1 855 478 2232
www.jupiteravionics.com